



Ω mega AIR CLEANER

sales@jokermachine.com, Phone: 909-596-9690
www.jokermachine.com

TOOLS NEEDED:

Sportster:

- 1/2" 12 Point Wrench
- 5/32" Allen Wrench
- 3/16" Allen Wrench

Softail:

- 3/8" 12 Point Wrench
- 5/32" Allen Wrench
- 3/16" Allen Wrench

IMPORTANT: A/C assembly will not run properly without re-mapping the E.F.I. system or re-jetting the carburetor.

NOTE: Use BLUE LOCTITE on all hardware

INSTALLATION

1. Completely remove stock air cleaner assembly. Keep stock gasket for step 4.
2. Softtail version only: Secure the loose pigtail with a zip-tie to the throttle position switch wiring harness.
3. Remove top cover. Keep top cover stand-offs on main a/c plate
4. Install base plate with (3) 1/4"-20 x 5/8" Allen screws using blue Loctite to the throttle body with the stock a/c gasket. Do not completely tighten down.
5. Install both vent plates, vent tubes (if using), a/c to head stand-offs and washers with breather bolts. (use blue Loctite on breather bolts)
6. Tighten down base plate screws.
7. Install the outer cover and K&N filter with (4) 1/4"-20 x 5/8" button head screws using blue Loctite.
8. Re-map EFI system or re-jet carburetor for increased air flow.
9. Enjoy!

