



Harley-Davidson® Softail 2000-06 Standard Rear Tire

Mounting Suggestions

Harley-Davidson® Softail 2000-06 Standard Rear Tire
One-Piece Seat

Mounting Suggestions

Harley-Davidson® Softail 2000-06 Standard Rear Tire
Two-Piece Seat

Mounting Suggestions

Harley-Davidson® Softail 2000-06 Standard Rear Tire
Solo Seat

Mounting Suggestions

Harley-Davidson® Softail 2000-06 Standard Rear Tire
Passenger Seat



Mounting Suggestions Harley-Davidson® Softail 2000-06 Standard Rear Tire One-Piece Seat



Baseplate Features:

Mustang Softail seats will NOT fit 1999-earlier FLSTS Heritage Springers. All seats are built on 16 gauge formed steel baseplates. A welded nose tab clips into the frame mount behind the gas tank. The baseplates have rubber supports at contact points and carpet to protect the fender.

Removal of Stock Seat

1. Remove two side mount screws on sides of front seat.
2. Remove rear fender screw.
3. Slide seat up and back to remove.
4. Remove rear mounting bracket from seat.*

Install Mustang Seat

1. Install stock rear mounting bracket onto Mustang seat baseplate.
2. Clip nose tab into the frame mount behind the gas tank.
3. Align and tighten rear fender screw.

***Note:** If stock rear mounting bracket is not available, use HD replacement or Mustang bracket #78037.

*Enjoy the comfort of your
new Mustang seat!*



These steps are guidelines to help you install your new Mustang Product. If you need further assistance, please call us at 800-243-1392 or 860-582-9633, Monday through Friday 9:00 – 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under [“Support”](#).

Refers to part numbers 75597, 76377, 75769, 75779, 75049, 75050, 75077, 75076, 75072, 75073, 75074

[back](#)



Mounting Suggestions Harley-Davidson® Softail 2000-06 Standard Rear Tire Two-Piece Seat



Baseplate Features:

Mustang Softail seats will NOT fit 1999-earlier FLSTS Heritage Springers. All seats are built on 16 gauge formed steel baseplates. A welded nose tab clips into the frame mount behind the gas tank. The baseplates have rubber supports at contact points and carpet to protect the fender.

Removal of Stock Seat

1. Remove one side mounting bolt on each side of the driver's seat.
2. Remove rear fender screw.
3. Slide seat back and up to remove.
4. Remove the side mounting inserts from frame (one each side) using a 3/4" wrench.
5. Remove rear mounting bracket from stock rear seat.

Mounting of Mustang Seat

1. Install rear mounting bracket taken from stock seat onto bottom of Mustang rear seat.
2. Locate and remove two 1/4-20 screws from rear of the Mustang solo baseplate.
3. Align front tabs of Mustang rear seat with holes in rear of solo baseplate.
4. Attach rear seat to solo seat using two 1/4-20 screws from step 2. Mustang seat is now a one-piece unit.
5. Insert nose tab into the frame mount at the base of the gas tank.
6. Align side mounts and install two 1/2-13 bolts (#78033) supplied with seat.
7. Align rear mounting tab and secure with stock screw.



These steps are guidelines to help you install your new Mustang Product. If you need further assistance, please call us at 800-243-1392 or 860-582-9633, Monday through Friday 9:00 – 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "[Support](#)".

Refers to part numbers 75084, 75085, 75086, 75087, 75089, 75090, 75094, 75095, 75096, 75097, 75098, 75225, 75226, 75230, 75230, 75231, 75259, 75593, 75594, 76187, 76188, 79120, 79121, 79130, 79131, 79258, 79259, 79278, 79279,

[back](#)



Mounting Suggestions Harley-Davidson® Softail 2000-06 Standard Rear Tire Solo Seat



Baseplate Features:

Mustang Softail seats will NOT fit 1999-earlier FLSTS Heritage Springers. All seats are built on 16 gauge formed steel baseplates. The baseplates have rubber supports at contact points and carpet to protect the fender. Mustang Softail solos have two side brackets that align with the large threaded holes in the Softail frames. Harley-Davidson® rear seats do not directly fit to Mustang solos.

Removal of Stock Seat:

1. Unscrew slotted side screws if stock seat is two-piece type.
2. Unscrew rear fender screw. NOTE: Spring loaded screws stay attached to brackets.
3. Slide seat back and up to remove.
4. Remove the side mounting inserts in frame (one on each side) using a 3/4" wrench.

Mounting of Mustang Seat:

(Hardware included: 2000-up solos are shipped complete with chrome side bolts, part #78033)

1. Be sure that 7/16" (head) bolts that secure the side mounting brackets to the bottom of the Mustang solo seat are not loose.
2. Insert front seat mounting tab into the frame mount behind the gas tank.
3. Align side brackets with large threaded holes in frame.
4. Secure side brackets with Mustang's chrome solo bolts part #78033 provided.

*Enjoy your new
Mustang Seat!*



These steps are guidelines to help you install your new Mustang Product. If you need further assistance, please call us at 800-243-1392 or 860-582-9633, Monday through Friday 9:00 – 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "[Support](#)".

Refers to part numbers 75593, 76188, 75089, 75084, 75086, 79121, 79120, 75096, 75094, 79278, 79258, 75230, 75225, 79714, 79716

[back](#)



Mounting Suggestions Harley-Davidson® Softail 2000-06 Standard Rear Tire Rear Seat



Baseplate Features:

Mustang Softail seats will NOT fit 1999-earlier FLSTS Heritage Springers. All seats are built on 16 gauge formed steel baseplates. The baseplates have rubber supports at contact points and carpet to protect the fender. All passenger seats are connected to the solo with two hidden screws.

Removal of Mustang Solo Seat:

1. Remove the side mounting bolts in frame (one on each side).
2. Slide seat back and up to remove.

Mounting of Mustang Rear Seat:

1. Remove stock rear mounting bracket (HD#52467-00 mounting bracket sold through dealers or Mustang bracket #78037) from stock seat and bolt to the Mustang passenger seat.
2. Remove two screws located at back of Mustang solo seat.
3. Align passenger seat front chrome tabs with threaded holes in back of solo baseplate.
4. Secure passenger seat and solo together with screws from step 1. Seat now becomes a 1-piece unit.
5. Insert nose tab into frame mount.
6. Align side mount brackets and install #78033 bolts.

***Enjoy your new
Mustang Seat!***



These steps are guidelines to help you install your new Mustang Product. If you need further assistance, please call us at 800-243-1392 or 860-582-9633, Monday through Friday 9:00 – 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under [“Support”](#).

Refers to part numbers 76187, 75090, 75098, 75085, 75087, 79131, 75097, 79130, 75095, 79279, 75231, 79259, 75226, 75594, 79715, 79717

[back](#)