



PRODUCT DESCRIPTION

2008-UP FLH TOURING MODELS	0208-2035-SMB	0208-2035-BM	0208-2035-CH
2005-2007 FLH TOURING, 2006-UP SOFTAIL & DYNA	0208-2036-SMB	0208-2036-BM	0208-2036-CH
96-03 SPORTSTER, 02-05 VROD, 96-05 SOFTAIL & DYNA	0208-2037-SMB	0208-2037-BM	0208-2037-CH
2004-UP SPORTSTER	0208-2038-SMB	0208-2038-BM	0208-2038-CH

NOSTALGIA MASTER CYLINDER CAPS

2008-UP FLH TOURING MODELS	0208-2074-SMB	0208-2074-BM	0208-2074-CH
2005-2007 FLH TOURING, 2006-UP SOFTAIL & DYNA	0208-2073-SMB	0208-2073-BM	0208-2073-CH
96-03 SPORTSTER, 02-05 VROD, 96-05 SOFTAIL & DYNA	0208-2072-SMB	0208-2072-BM	0208-2072-CH
2004-UP SPORTSTER	0208-2075-SMB	0208-2075-BM	0208-2075-CH

1. Place motorcycle on a secure lift or stand.

2. Remove the factory master cylinder cap, gasket, and screws. The factory screws will be reused.

Note: On 0208-2036/2037/2072/2073 applications, remove the rubber gasket from the cap and sight glass.



3. Inspect the gasket for damage. Replace if necessary. Check brake fluid level and fill to factory specifications.

4. Install the RSD master cylinder cap using the stock gasket and hardware.

Note: On 0208-2036/2037/2072/2073 applications, make sure the center hole on the gasket slides completely onto the center stand-off.

Note: On 0208-2038/2075 use the factory opaque plastic plate with rubber gasket.



5. Install the factory master cylinder cap screws. Refer to the HD service manual for proper torque specs.



6. Install the adhesive backed RSD logo badge of your choice.



7. Hit the road!